HOW TO ACHIEVE THE BEST FINISH USING MICRO-MESH®

The polishing of surfaces can be very exacting. Success or failure depends on the technician's knowledge of, and his ability to follow, an established sequence.

MICRO-MESH® Can be Used by Hand. Wrap the abrasive around a foam sanding block to give you even, uniform pressure during your sanding strokes.

MICRO-MESH® Can be Used With an Electric or Pneumatic Random Orbital Sander. Keep sanders to no more than 3500 rpms. Do not use with high speed die grinders or vibratory sanders. Ripples and swirls are typically caused by sanding with an uneven motion, tilting the sander, or working in one spot too long. For best results, sand smoothly with even, sweeping motions.

Keep Belt Machines at 5500 Rpms or Less. Adjust pressure and tension so that the contact point allows the abrasive to work without smearing. Typically durometers of 30-40 in rubber are best for a cushioned abrasive or cotton buffing wheels work well. Do not use lubricants containing solvents, alcohol or ammonia that could delaminate the MICRO-MESH®.

Pressure Should be Light. Remember the cushioned abrasive cuts with the abrasive crystal tips. The sharp cutting edges are floating on a resilient matrix. Extreme pressure pushes the tips back into the matrix rendering them ineffective and resulting in surface smearing, burning, and possible orange peel and distortion. If using with a belt machine, polish on the slack of the belt on using a soft contact wheel. If using a random orbital sander, polishing steps may require a soft back up pad between the MICRO-MESH® disc and the sander head.

KEEP EVERYTHING YOU USE CLEAN. This includes equipment, sandpapers, MICRO-MESH®, and all wiping materials. A minor scratch here or there is not a crisis situation, but picking up a piece of metal or other contaminate from the top of a work area can be a disaster. Watch where you set things down.

Acceptable Cleaning and Maintenance Materials:

100 % cotton flannel
Genuine chamois, not synthetic or imitation
Biodegradable liquid detergent
MICRO-MESH® Anti-Static cream
MICRO-GLOSS® polish and cleaner
WinBRIGHT Spray plastic cleaner
Bug Blaster Spray bug remover

Unacceptable Cleaning and Maintenance Materials:

Paper towels or other paper products Shop towels or synthetic fiber fabrics Commercial window cleaners Any product containing ammonia or solvents or alcohol Clean the Work Surface between each step, especially in cracks and crevices. Flush surface several times with clean water to remove dust and dirt before touching it with anything. Clean abraded particles from the work piece by rinsing and then dry and inspect.

Inspect the Work Piece between steps with a bright light to ensure you are removing the previous scratch pattern before continuing on.

Keep the Abrasives Clean. Keeping them clean will improve performance and extend life.

To Avoid Scratching the Surface, do not wear watches, rings, or bracelets. Long fingernails should be covered with gloves.

For Superficial and Light Surface Damage, use MICRO-GLOSS® liquid abrasive following the directions on the label of the bottle.

For Deep Damage and Crazing, you will be required to remove the damage firstly with sandpaper and then restore the surface to its original state using MICRO-MESH®. After damage is removed by using sandpaper in a succession of steps from coarse to fine, ie: 120 grit, 220 grit, 400 grit wet/dry, then begin the MICRO-MESH® series with MICRO-MESH® 1500 and proceed through the series to 12000 or until the original surface is matched.

Use a Straight-line Crossing Pattern. Do not use a circular pattern except in the final hand buffing or antistatic operations. When using a random orbital sander, use sweeping motions from left to right for one grit, then change the pattern to an up and down motion on the next.

Using MICRO-MESH® with Water and a few drops of detergent will generally result in a less effort having to be used and a slightly better finish. Only use enough water to provide lubricity to the surface, but not so much that poor contact is made with the work piece.

DO NOT wear out one of the meshes by trying to make it do too much work on your first step. If your estimated damage is not readily removed, go immediately to the next coarser mesh. Removing the initial damage with the sandpaper series will take up 85% of the restoral time. The MICRO-MESH series and the buffing procedures will take as little as 15% of the time. **DO NOT** skip steps in either the sandpaper or the MICRO-MESH® series.

Work an area slightly larger with each step to blend. Working one small area on a highly curved section could create flat spots or distortion.

IMPORTANT NOTICE: Micro-Surface Finishing Products, Inc. ("Micro") MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. User is responsible for determining whether this product is fit for a particular purpose and suitable for user's method of application.

LIMITATION OF REMEDIES AND LIABILITY: If this product is proved to be defective, THE EXCLUSIVE REMEDY, AT MICRO'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT. Micro shall not otherwise be liable for loss or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted, including negligence, warranty or strict liabilities.

MICRO-MESH REGULAR

DESCRIPTION: A scientifically engineered series of cloth-backed, cushioned abrasives.

MICRO-MESH Regular was originally developed to polish most hard plastics. It will restore surface finish, clarity, and transparency quickly and easily. MICRO-MESH will also polish fiberglass, epoxy, gel-coat, raw and finished wood, gold and silver, cultured marble etc.

MATERIALS: Silicon Carbide crystals on a resilient layer over a cloth back. The material back is stamped with the following grade number for easy identification:

1500	3600	*8000	
1800	4000	*12000	
2400	6000		
3200		*aluminum oxide cry	stals.

AVAILABLE IN: Sheets: 3" x 6" **Discs**: 5" - 6" - 8"

6" x 12" other sizes available upon request 12" x 12" loop and PSA backing available

Rolls: 4" x 50' **Tapes:** Various call for assistance

6" x 50' 6" x 25'

12" x 25' **Soft Touch Pads:** 2" x 2" 3" x 4"

Kits: Plastic, Aquarium, Wood, Hobby

Tub/Spa, Marine, Vinyl, etc.

Buffers & Files: 1/2" x 5 3/4"

5/8" x 5 3/4"

Same grit on both sides or multiple grits up to 2 per

side.

STORAGE &

HANDLING: When stored between 0-120 degrees Fahrenheit and in a clean and dry environment, life is nearly unlimited. No special handling is required.

APPLICATION: MICRO-MESH Regular is not an aggressive stock remover. Common sandpaper is required for the removal of deep scratches before using MICRO-MESH.

Complete instructions are available on request from MICRO-SURFACE at 1-800-225-3006. Special sizes and shapes are available, please contact MICRO-SURFACE. Kits can be made to specification.

01/2004 Technical Bulletin-#11