



MICRO-SURFACE
FINISHING PRODUCTS INC.

LIQUIDS



MICRO-GLOSS™

A general purpose water-based liquid abrasive which uses a 1-micron aluminum oxide abrasive crystal to achieve a fine finish on acrylics, plastics, polycarbonate, fiberglass, wood, silver, gold, copper, brass paint urethanes, laquers, and polyesters to name a few. This unique liquid removes hairline scratches, haziness, and halos untouched by other products. Contains no fillers or wax that could cause yellowing. Remove scratches and imperfections with Micro-Gloss and buff back to optical clarity. Micro-Gloss will remove a 4000 Micro-Mesh or 1500 CAMI scratch pattern. Approved as safe for use on inside and outside surfaces of f-16 aircraft. Approved for use by Boeing, Spec D6-52021. Use by hand or machine with a TufBuf lambswool polishing pad or foam sponge pad. Available in 1 oz, 2 oz, 4 oz, 8oz, or gallon containers. NSN# 5350-01-334-8997.

MICRO-GLOSS#5

The same as above, but with a 5 micron aluminum oxide crystal. Use when a more aggressive cutting action is required. Follow up with regular Micro-Gloss. Available in 1 oz, 2 oz, 4oz, 8oz, and gallon containers.

MICRO-FINISH

The final step to remove any residual haze. Use this special polish to brighten and give a pristine finish. Available in 2oz, 4 oz, 8oz, and gallon containers.

FINAL FINISH

A soft vinyl conditioner which combines a high-quality carnuba wax with a soft cutting liquid abrasive. Use as the final step on vinyl convertible windows and boat side curtains. Available in 2oz, 4oz, 8oz, and gallon containers.

ANTI-STATIC CREME (Not Pictured)

This liquid contains a protectant and is designed to remove static electricity that could cause dirt and dust to be drawn back to your newly polished surface.