

FINAL FINISH PROCEDURES

Rich conditioner that protects and adds luster to vinyl, plastic and polycarbonate surfaces.

Regular use will add value and life.

1. Apply a thin film of Final Finish Cream to the surface, using a clean, dry, flannel cloth.

Do not use paper towels, micro fiber wipers, industrial wipers

as any of these will scratch transparencies.

Hand buffing or a rotary tool and soft foam pad may be used in this process. If using a rotary tool, do not use one rated over 2500 rpms.

- 2. Buff the product into the transparency using slow methodical strokes. Stroke pattern is not of significance in this process, ie: straight line versus circular. Avoid using pressure. A light touch works best. Work in small 1 foot square areas so you can easily incorporate the cream into the surface before it dries.
- 3. If the cream dries on the surface it will be more difficult to work into the surface and scratching could occur. You can mist the surface with clean water and continue buffing if this happens. It is also advisable to mist the flannel cloth slightly prior to beginning this process.
- 4. Avoid using too much product. If too much is used gumming on the surface can occur, making the buffing process more laborious.

For technical support contact Micro-Surface Finishing Products, Inc. at 800-225-3006

IMPORTANT NOTICE: Micro-Surface Finishing Products, Inc. ("Micro") MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. User is responsible for determining whether this product is fit for a particular purpose and suitable for user's method of application.

LIMITATION OF REMEDIES AND LIABILITY: If this product is proved to be defective, THE EXCLUSIVE REMEDY, AT MICRO'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE (KIT) PRODUCT. Micro shall not otherwise be liable for loss or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted, including negligence, warranty or strict liability.